

Vocas FCR-15 Crosse d'épaule flexible Kit Advanced



Description brève du produit :

Le Kit Advanced FCR-15 est une épaulière professionnelle Vocas compatible et recommandée pour les caméras possédant une poignée supérieure.

Codes produits :

Référence 0255-3010

EAN13 : 8720041002505

CUP : -

Description du produit :

FCR-15 Advanced kit consisting of the flexible camera rig FCR-15 (0350-3000), the FCR-15 top handle (0350-3010) and the leather handgrip kit (0390-0002). The Advanced kit is compatible with a wide variety of cameras and is recommended for cameras without a proper tophandle and to which a third party viewfinder or LCD needs to be mounted..

The FCR-15 is a 15 mm height adjustable camera rig with an ARCA balancing system and an extremely flexible shoulder pad, which offers a high variety of shoulder mounting positions. The top of the rig is equipped with an ARCA camera dovetail plate, offering quick release sliding and balancing options for your camera setup. The ARCA camera dovetail plate slides in from the front or the top of the rig.

On the right rear end, the shoulder pad is attached to the rig via an extender to a vertical 19 mm tube. The quick lock lever of the extender enables you to set the shoulder pad quickly in many different positions. For instance, the shoulder pad can be used directly underneath the rig for a comfortable shoulder set-up, or into a compact chest support set-up. Further, the position of the

shoulder pad can be set about 100 mm further backwards, while adjusting the angle of the shoulder pad as well.

The quick lock lever also enables you to take out the shoulder pad and attach the shoulder pad to the rig in an offset position, transforming your shoulder rig in a offset shoulder rig. The variety in positioning the shoulder pad is a unique feature, making this rig compatible with any DSLR camera, compact solid state camera and compact cine cameras.

By using any of the above setups, the rig is a perfect solution for using the cameras front viewfinders and LCD screens, and LCD screens and viewfinders on the back of the camera.

The quick lock lever enables you to expand and collaps your rig in just a second. Perfectly easy for packing your rig into your small camera bag.

The height adjustable front rails of the FCR-15 provide compatibility with almost any camera DSLR camera, with or without battery pack, solid state camcorders and compact cine cameras! The bottom of the plate is equipped with several 1/4" and 3/8" thread holes for mounting all kind of tripod plates.

An optional 15 mm clamping block (0350-2010) can be mounted to the back of rig, offering the possibility to mount any 15 mm rail accessory to the back of the camera, for instance a battery, recorder, monitor or counter weight.

The top handle attaches to the offset 19 mm vertical tube of the FCR-15, which enables you to adjust the position of the handle to the left and the right. Because the top handle excists of two parts, a lower bracket and a ergonomically designed handgrip bracket, the height and the lenght of the handgrip can be easily adjusted.

An hexagonal key is integrated into the lower bracket, offering the possibility to collaps the top handle easy and fast. The top handle offers multiple 1/4" and 3/8" thread holes, two cold shoe attachments and a 15 mm integrated viewfinder adapter. The viewfinder adapter enables you to mount any third party viewfinder or LCD screen from the top, via any of the Vocas NATO rail solutions.

The leather handgrip kit offers a nice, stable and comfortable grip while using the shoulder rig.

DESCRIPTION :

- Rosette : Optional
- Shoulder pad : Adjustable, Removable, Toolless
- Shoulder pas size : Standard

- Bars position : Front, Optional rear
- Bar system : 15mm
- Height adjustable : Yes
- Camera mounting points : 2
- Package included : 0350-3050 ARCA dovetail plate, 0350-9210 15 mm bars (2x)
- Material : Aluminium, Cork, leather, Rubber
- Color : Black
- Weight (gr.) : 1,750